

# Four Zone Wireless Receiver with One Shared Alarm Output SWPREC1



## FEATURES

- **SWPREC1** wireless receiver is compatible with **SWPB series** solar powered wireless photobeam sensors or other Visonic sensors
- Receive RF signals from its learned sensor and provide alarm beeping sound
- Ability to Indicate which zone is alarming and provide tamper switch, battery low, supervision reports for each zone
- N.O./N.C. output
- Ideal for driveway, surrounding walls, swimming pool and other places



Please read the Manual before attempting to use this product.



## CAUTION

RISK OF ELECTRIC SHOCK  
DO NOT OPEN!



TO REDUCE THE RISK OF ELECTRICAL SHOCK,  
DO NOT OPEN COVERS (OR BACK).  
NO USER SERVICEABLE PARTS INSIDE.  
REFER SERVICING TO QUALIFIED  
SERVICE PERSONNEL.



### Disposal of Old Electrical & Electronic Equipment (Applicable in the European Union and other European countries with separate collection systems).

This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. The recycling of materials will help to conserve natural resources. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

## CAUTION

### 1. Handle this product with care

Avoid any shock or bumping of the product. Improper handling could damage the product.

### 2. Requires a proper operating environment

This product is designed for outdoor use.

### 4. Cleaning

Do not use aerosol cleaners.

### 5. Servicing

Do not attempt to service this product by yourself. Refer all service to qualified servicing personnel.

### 6. Retain Instructions


The safety and operating instructions should be retained for future reference.

## PACKAGE CONTENTS

- One (1) Single Zone Wireless Receiver
- One (1) Connector
- One (1) Jumper
- One (1) 9V DC Battery
- One (1) User Manual

For any returns, please include all components listed above with original packaging in **Resalable Condition**. **Absolutely No Returns** will be accepted if any component is missing/damaged.

## Dimensions



## PROGRAMMING AND OPERATION

Power on the receiver, “dididi” will be heard indicating that the device is self-checking and that the device is OK. For new receiver start on STEP TWO. For a used devices start on STEP ONE, if you want to clear the memory, If not, start from STEP TWO.

**STEP ONE:** Refer to item 4 of the following to delete all the learned devices.

**STEP TWO:** To learn a new device into memory—Press the "SET" key and hold it on, 3 seconds later, a beep tone is heard, release the "SET" key, the receiver will enter learning mode. Let the **SWPB series** wireless photobeam sensor send a RF signal ----- press tamper key of the Photobeam sensor ( with “R” mark) and hold it on, then turn on the power switch to make a test RF sending, the Photobeam will beep "di,di--" to show the new sensor has been learned into its memory successfully. Repeat above operation to make another RF sending for learning next sensor. After all devices have been learned, press and release the "SET" key to quit learning mode, ‘di,di’ will be heard.

Beep (di,di--) for successfully learning a new device;

Beep (didididi,didididi,didididi) for memory is full;

Up to 4 Photobeam sensors can be learned into a wireless receiver.

The alarm beeping is different for each zone, and at the same time the alarming zone LED is on.

- For zone 1----- one 0.3s long beep                    (repeat 5 times)
- For zone 2----- two short beeps                    (repeat 5 times)
- For zone 3----- three short beeps                    (repeat 5 times)
- For zone 4----- four short beeps                    (repeat 5 times)

### Setting Zone 1 to Delay 7 seconds Before Alarming:

Power off the **SWPREC1** receiver. Press the "SET" key of the **SWPREC1** receiver and hold it on then power on the **SWPREC1**, "didididi" is heard, then release the "SET" key, "dididi" is heard to show the 7s delay setting is OK. When zone 1 trips, it will have a 7 second delay before it sounds the beeper, however if a recovery signal is received from the beam sensor within 7 seconds the beeper will not sound.

### Deleting One Zone / All Zones:

Press the "SET" key of the **SWPREC1** receiver and hold it on up to 6 seconds, two short beeping (bibi) will be heard, then release the "SET" key, the zone LED will be turned on one by one, then all zone LEDs are turned on, 5 seconds for each zone, press the "SET" key to delete the zone when its zone LED is on, (bibi) will be heard to show the relative zone has been cleared. When all zone LEDs are on, press the "SET" key to delete all zones.

### "TRBL" LED

When the **SWPREC1** receives "tamper open" report, "battery low" report, or it cannot receive any information in 8 hours, the relative zone "trbl" LED will be on. Press "SET" key to see the "trbl" details:

1. For tamper open, the "trbl" LED flashing is -----0.3s on / 0.3s off.
2. For supervision fail, the "trbl" LED flashing is -----0.9s on / 0.9s off.
3. For BAT LOW, the "trbl" LED will keep steady on for 3.6 seconds.

## LIMITED WARRANTY

### LIMITED ONE (1) YEAR WARRANTY AND EXCLUSIONS

Manufacturer warrants to the original consumer purchaser and not for the benefit of anyone else that this product at the time of its sale by Manufacturer is free of defects in materials and workmanship under normal and proper use for one (1) year from the purchase date.

Manufacturer's only obligation is to correct such defects by repair or replacement, at its option, if within such one (1) year period the product is returned prepaid, with proof of purchase date, and a description of the problem. This warrant excludes and there is disclaimed liability for labor for removal of this product or reinstallation. **This warranty is voided if this product is installed improperly or in an improper environment, overloaded, misused, opened, abused, or altered in any manner, or is not used under normal operating conditions or not in accordance with any labels or instructions. There are no other implied warranties of any kind, including merchantability and fitness or a particular purpose**, but if any implied warranty is required by the applicable jurisdiction, the duration of any such implied warranty, including merchantability and fitness of or a particular purpose, is limited to one (1) year. **Manufacturer is not liable for incidental, indirect, special, or consequential damages, including without limitation, damage to, or loss of use of, any equipment, loss sales or profits or delay or failure to perform this warranty obligation.** The remedies, provided therein are the exclusive remedies under this warranty, whether based on contract, tort or otherwise.